EP-008B ADAPTER YAMAHA G22 AND G23

SAFETY WARNING

1-ALWAYS WEAR EYE PROTECTION 2-PLACE KEY SWITCH IN THE OFF POSITION 3-SET PARKING BRAKE

INSTALLATION INSTRUCTIONS

- 1-TOOLS NEEDED 1(ONE) 9/16 SOCKET AND 1(ONE) 9/16 WRENCH.
- 2-IF CART IS EQUIPPED WITH BUMPER, BUMPER MUST BE REMOVED PRIOR TO INSTALLATION. KEEP HARDWARE WHEN REMOVING BUMPER AS YOU WILL NEED IT TO INSTALL ADAPTER. HARDWARE SUPPLIED (2-3/8 X 1 1/2" BOLTS)(2-3/8" NUTS)(2-3/8" LOCK WASHERS)
- 3-SLIDE ADAPTER ALONG TOP OF CHASIS AS SEEN IN ILLUSTRATION BELOW.
 THEN INSTALL HARDWARE AND TIGHTEN EVENLY.

